

Toggle switch McPower „FLAIR“


IP44, 250V~/10A, flush-mounted

TECHNICAL DETAILS: · Flush-mounted two-way switch with rocker · 250 V~ / 10 A · Includes frame · IP44 – splash-proof · Dimensions (W × H × D): 80 × 80 × 40 mm · Suitable for cavity wall boxes with Ø 68 mm · Ideal for use in damp areas such as utility rooms, basements, bathrooms or terraces

SAFETY INSTRUCTIONS: Please keep the operating instructions for future reference. Inspect the device regularly for damage. Do not modify the product or any accessories. Do not insert any objects into connection sockets or openings. The product complies with protection class IP44 and is protected against the ingress of solid foreign objects and splashing water. It is suitable for temporary outdoor use. However, the product must not be exposed to permanent moisture, heavy rain or standing water and is not intended for underwater use. Do not short-circuit the connections. Use the product only if it is in perfect working condition. Never operate a defective device. The device must not be modified in any way – risk of electric shock and injury. Avoid extreme conditions such as excessive heat or cold, heavy moisture, microwave exposure, mechanical pressure and strong vibrations. When used outdoors, ensure that sockets and connections are correctly installed and protected from direct water exposure. Avoid overloading the socket by not connecting several high-power devices at the same time. Overloaded sockets may overheat and cause a fire hazard. Always disconnect the power supply before connecting or disconnecting the device. Electrical work, installation and repairs may only be carried out by qualified electricians. Do not insert metallic objects or fingers into the socket to prevent short circuits or electric shock – DANGER TO LIFE. Clean the device only with a soft, dry or slightly damp cloth. Do not use abrasive cleaners or chemical cleaning agents. Electrical components must not come into direct contact with water or moisture. Do not bend, crush, pinch or otherwise damage the cables. In case of questions, defects, mechanical damage or other problems, please contact the dealer or manufacturer. If you have any doubts about the safety of the product or if it does not function properly, have it inspected and, if necessary, repaired by a qualified electrician. The product is not a toy and must be kept out of reach of children. Please note that the product itself as well as packaging materials such as plastic bags, films, polystyrene parts, small parts and insulation materials may pose a danger to children.

ASSEMBLY

1. Switch off the fuse and verify that the circuit is de-energized. **2.** Strip the wire ends by approx. 12 mm. **3.** Remove the cover. **4.** The connections are labeled „L1“ and „X1“. **5.** Secure the conductors in the screw terminals as shown in the diagram below. Make sure that no wires are connected incorrectly and that no strands are protruding or sticking out. **6.** Insert the switch into the flush-mounted wall box and tighten the mounting claws securely. **7.** Place the frame over the installed light switch and attach the rocker to the switch.



DISPOSAL INSTRUCTIONS: By separating, recycling and disposing of old appliances in this way, you are making an important contribution to protecting our environment. Packaging can be disposed of free of charge in accordance with local regulations at the appropriate collection centres. According to the European WEEE Directive, electrical and electronic appliances may not be disposed of with household waste. Their components must be recycled or disposed of separately, as toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the German Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its life to the manufacturer, the point of sale or to public collection centres set up for this purpose. Details are regulated by the respective state law. The wheeled bin symbol on the product, operating instructions and/or packaging indicates these regulations.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:

EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:

FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant:

ES: Encontrará una versión multilingüe de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

<http://ettgroup.de/product/1535977>