

Adapter plug McPower

2 USB ports: 1 USB-A and 1 USB-C PD 20W

TECHNICAL DETAILS: Protective-earth socket with max. 16 A, 3,680 W · 1× USB-A max. 5 V / 3 A (15 W) · 1× USB-C 9 V / 2.22 A – 12 V / 1.67 A (max. 20 W) · PowerDelivery · IP20 – for indoor use only · USB standby consumption: < 0.1 W · No-load power consumption in accordance with Regulation (EU) No. 2019/1782

SAFETY INSTRUCTIONS: Please read these safety instructions carefully and keep them for future reference. This adapter is intended solely for connecting electrical devices to the 230V~ mains supply and for charging compatible USB devices. Any other use is considered improper and may lead to damage or hazards. The product must not be opened, modified, or repaired; repairs may only be carried out by qualified professionals. Use the product only in dry indoor environments and protect it from moisture, water and condensation (IP20). Do not remove the rating label, as it contains important technical information. Work on the 230V~ mains is dangerous—always connect the product only to properly installed, grounded sockets. Never use the adapter if the housing or plug shows visible damage, and do not touch it with wet or damp hands. Ensure that the maximum load rating of the adapter is not exceeded to avoid overload or fire hazards. Do not connect high-power appliances such as fan heaters, radiant heaters, air conditioners or kettles if they may exceed the permitted load. Do not cover the adapter and always provide adequate ventilation to prevent overheating. Adapters must never be connected in series ("daisy-chained"). Use only suitable and undamaged charging cables for the USB ports and ensure that the maximum USB output power is not exceeded. The USB ports are intended exclusively for charging compatible devices and are not suitable for operating high-power equipment via USB. Keep the product out of reach of children and animals, as they may not recognize electrical hazards. Check the adapter regularly for visible damage and take it out of service immediately if any irregularities occur. The manufacturer assumes no liability for damage caused by improper use, failure to follow these instructions, or modifications to the product.



GENERAL SAFETY INSTRUCTIONS: The product must not be modified in any technical or mechanical way, as this will immediately void its operating approval and conformity. The type plate or printed marking must never be removed under any circumstances. Before each use, inspect the product for any signs of damage. If any damage is visible, the product must be checked, repaired, or replaced by a qualified specialist. A damaged or defective product must not be used again and must be disposed of in accordance with applicable regulations. Ensure that all packaging materials and accessories, especially small parts such as screws or plastic films, are stored safely out of reach of children and animals, as they may pose a choking hazard. The manufacturer assumes no liability for material or personal damage resulting from improper use, misuse, failure to follow the instructions, or any modifications to the product. Always ensure that the product is never operated, placed, or stored within reach of children or animals. Keep this manual in a safe place and include it together with the packaging when passing the product on to third parties. We reserve the right to make changes to the product, its packaging, or this manual at any time.

DISPOSAL INSTRUCTIONS: By separating, recycling and disposing of old appliances in this way, you are making an important contribution to protecting our environment. Packaging can be disposed of free of charge in accordance with local regulations at the appropriate collection centres. According to the European WEEE Directive, electrical and electronic appliances may not be disposed of with household waste. Their components must be recycled or disposed of separately, as toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the German Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its life to the manufacturer, the point of sale or to public collection centres set up for this purpose. Details are regulated by the respective state law. The wheeled bin symbol on the product, operating instructions and/or packaging indicates these regulations.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:

EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:

FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant:

ES: Encontrará una versión multilingüe de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

<http://ettgroup.de/product/1300668>