

Desktop socket outlet McPower „BW-64“

3× sockets, 2× USB-A, 1× USB-C PD 20W

TECHNICAL DETAILS: • Three protective-earth (Schuko) sockets with child protection / shutter • ON/OFF switch • 230 V / 50 Hz • Max. 16 A, 3,600 W • 2× USB-A and 1× USB-C • 5.0 VDC 3.0 A, 15.0 W (Type A+A, A+Cor A+A+C) • 5.0 VDC 3.0 A, 15.0 W (Type C or A) • 9.0 VDC 2.22 A, 20.0 W (Type C) • 12.0 VDC 1.67 A, 20.0 W (Type C) • Power Delivery • Dimensions (W×H×D): 75 × 75 × 75 mm • Includes approx. 1.5 m power cable with protective-earth plug • IP20 – for dry indoor use only • USB standby consumption: < 0.1 W • No-load power consumption according to Regulation (EU) No. 2019/1782

SAFETY INSTRUCTIONS: Power strips must not be connected in series ("daisy-chaining"), as this can lead to overloading and, in the worst case, pose a fire hazard. Every power strip has a maximum current rating (indicated in amperes), which must never be exceeded to prevent overheating. Use only power strips with protective earth (Schuko) to reduce the risk of electric shock. High-power devices such as fan heaters or kettles should only be connected to a power strip for short periods, as most power strips are not designed for continuous operation with such loads. Power strips must not be used in damp rooms or outdoors unless they are explicitly approved for such environments. Ensure that the power strip is never covered to avoid overheating, and check it regularly for damage such as cracks in the housing or bent contacts. When using devices that operate directly on the 230V~ mains, extra caution is required. Make sure all connected devices are in proper working condition and do not use damaged cables, plugs, or housings, as this can create dangerous situations. Verify that the devices are suitable for 230V~ operation and connect them only to sockets rated for the required current. The power supply should only be used on circuits equipped with a residual current device (RCD), as this will immediately interrupt the circuit in the event of a fault current and protect against life-threatening electric shocks. Never touch electrical devices with wet or damp hands and ensure they are operated and stored out of reach of children or persons who may not be able to assess electrical hazards. Faulty devices must be disconnected from the mains immediately and must not be used further. Never leave electrical devices running unattended and do not cover them during operation unless explicitly permitted in the user manual. Always remember: electricity is dangerous. Handle electrical devices with care, follow all safety instructions, and consult a qualified professional if in doubt. Please also observe the specific ingress protection (IP rating) of the product

GENERAL SAFETY INSTRUCTIONS: The product must not be modified in any technical or mechanical way, as this will immediately void its operating approval and conformity. The type plate or printed marking must never be removed under any circumstances. Before each use, inspect the product for any signs of damage. If any damage is visible, the product must be checked, repaired, or replaced by a qualified specialist. A damaged or defective product must not be used again and must be disposed of in accordance with applicable regulations. Ensure that all packaging materials and accessories, especially small parts such as screws or plastic films, are stored safely out of reach of children and animals, as they may pose a choking hazard. The manufacturer assumes no liability for material or personal damage resulting from improper use, misuse, failure to follow the instructions, or any modifications to the product. Always ensure that the product is never operated, placed, or stored within reach of children or animals. Keep this manual in a safe place and include it together with the packaging when passing the product on to third parties. We reserve the right to make changes to the product, its packaging, or this manual at any time.



DISPOSAL INSTRUCTIONS: By separating, recycling and disposing of old appliances in this way, you are making an important contribution to protecting our environment. Packaging can be disposed of free of charge in accordance with local regulations at the appropriate collection centres. According to the European WEEE Directive, electrical and electronic appliances may not be disposed of with household waste. Their components must be recycled or disposed of separately, as toxic and hazardous components can cause lasting damage to health and the environment if disposed of improperly. As a consumer, you are obliged under the German Electrical and Electronic Equipment Act (ElektroG) to return electrical and electronic equipment free of charge at the end of its life to the manufacturer, the point of sale or to public collection centres set up for this purpose. Details are regulated by the respective state law. The wheeled bin symbol on the product, operating instructions and/or packaging indicates these regulations.



DE: Eine mehrsprachige Version dieser Anleitung und die Konformitätserklärung finden Sie unter folgendem Link:

EN: A multilingual version of this manual and the Declaration of Conformity can be found at the following link:

FR: Vous trouverez une version multilingue de ce manuel et la déclaration de conformité sur le lien suivant:

ES: Encontrará una versión multilingüe de estas instrucciones y de la declaración de conformidad en el siguiente enlace:

<http://ettgroup.de/product/1300667>